










Uputstvo za montažu 10 Azala / Installation instructions 10 Azala

(1)  1. Otvorite dispenser pomoću ključa. 1. Open the dispenser with the key.	(2)  2. Pričvrstite dispenser za zid koristeći set šrafova. 2. Fix dispenser to the wall using the screws-kit.	(3)  3. Izvucite pumpu. 3. Extract the pump.	(4)  4. Odvijte poklopac kertridža i zavrnite pumpu. 4. Unscrew the cartridge cap and screw the pump.
(5)  5. Umetnite kertridž sa pumpom u dozator.* Presecite plastičnu oznaku (a).** 5. Insert the cartridge with pump into dispenser.* Cut the plastic tab (a).**	(6)  6. Otvorite prostor za baterije pritiskom na kukicu (c) i umetnite 4 baterije tipa AA. 6. Open the battery compartment by pressing the hook (c) and insert nr. 4xAA batteries.	(7)  7. Zatvorite odeljak za baterije. 7. Close the battery compartment.	(8)  8. Zatvorite dispenser. 8. Close the dispenser. Preporučena visina za montažu je od 900 do 1200 mm. / Recommended mounting height 900 to 1200 mm.

*** VAŽNO! / IMPORTANT!** Proverite da pumpa nije spuštena. / Make sure that the pump isn't lowered.




** Samo za disp. 10 Azala sapun.


** Only for art. 10 Azala soap.

Uputstvo za zamenu kertridža 10 Azala


Cartridge change instructions 10 Azala



1. Izvucite pumpu i kertridž.
1. Extract pump and cartridge.



2. Odvrtite pumpu.
2. Unscrew the pump.




(a)




(b)

3. Odvijte poklopac kertridža (a) i zavrtite pumpu (b).
3. Unscrew the cartridge cap (a) and screw the pump (b).




4. Umetnite pumpu i kertridž.*
4. Insert pump and cartridge.*

*** VAŽNO! / IMPORTANT!** Proverite da pumpa nije spuštена. / Make sure that the pump isn't lowered.




Uputstvo za zamenu kertridža 10 Azala


Cartridge change instructions 10 Azala




1. Izvucite pumpu i kertridž.
1. Extract pump and cartridge.



2. Odvrtite pumpu.
2. Unscrew the pump.




3. Odvijte (a) i uklonite pumpu (b).*
3. Unscrew cap (a) and remove the pump (b).*




Nova pumpa /
New pump

4. Odvijte poklopac kertridža (c) i zavrtite pumpu (d).
4. Unscrew the cartridge cap (c) and screw the pump (d).




5. Ubacite pumpu do kraja.
5. Insert pump pushing all the way in.



6. Umetnite pumpu i kertridž.**
6. Insert pump and cartridge.**

*** VAŽNO! / IMPORTANT!** Proverite da pumpa nije spuštена. / Make sure that the pump isn't lowered.



** Ispraznite pumpu pre odvrtanja.

** Empty the pump before unscrewing.