

INSTRUKCIJE / INSTRUCTIONS

Otvorite dispenser pomoću priloženog ključa.

KORAK 1

Pomerajući odgovarajući prekidač desno ili levo,

izaberite podešavanje DAY – NIGHT – 24 h:

- **DAY** – radi automatski samo danju.
- **NIGHT** – radi automatski samo u mraku.
- **24 h** – radi 24 sata dnevno.

KORAK 2

Izaberite vremenski interval rada (7,5 – 15 – 30 minuta) pomerajući odgovarajući prekidač desno ili levo.

Ubacite novu sprej-bocu.

Ubacite dve alkalne baterije LR6 (AA) u odgovarajući prostor.

Izaberite režim ON. (PAŽNJA! NE STOJTE PRED DISPENZEROM DA BISTE IZBEGLI RASPRŠIVANJE SPREJA U LICE I OČI!)

Zatvorite dispenser.



Open the dispenser with the MP Key.

STEP 1

Select setting DAY – NIGHT – 24 h moving the apposite lever to the right or left:

- **DAY** – operates automatically only with light.
- **NIGHT** – operates automatically only with darkness.
- **24 h** – operates 24 h a day.

STEP 2

Select the interval mode of operation (7,5 – 15 – 30 minutes) moving the apposite lever to the right or left.

Insert new aerosol can.

Insert two AA-cell batteries into unit and is recommended alkaline batteries for longer usage.

Select ON mode (ATTENTION! DO NOT STAND IN FRONT OF DISPENSER IN ORDER TO AVOID SPRAYING ON TO FACE AND INTO EYES!)

Close the dispenser.



Made in Italy